

KRÜGER

KRA41

- | No. | Description |
|-----|--------------------------|
| ① | Castor ASS.Y |
| ② | Case Lower |
| ③ | Wheel Cap |
| ④ | Wheel Rear |
| ⑤ | Cramp Rotary |
| ⑥ | Washer |
| ⑦ | Pre-Filter |
| ⑧ | Filter Paper bag |
| ⑨ | Motor Supporter Lower |
| ⑩ | Power Cord Supporter |
| ⑪ | Tapping Screw |
| ⑫ | Float Cylinder |
| ⑬ | Air Inlet |
| ⑭ | Motor Cushion Lower |
| ⑮ | Noise elimination sponge |
| ⑯ | Wet/dry Motor |
| ⑰ | Internal Wire ASS.Y |
| ⑱ | Motor Cushion Upper |
| ⑲ | Circular Washer |
| ⑳ | Screw SJ2821 |
| ㉑ | Switch Supporter |
| ㉒ | Switch |
| ㉓ | Screw SJ2823 |
| ㉔ | Case Upper |
| ㉕ | Screw SJ2823 |
| ㉖ | Handle ASS.Y |
| ㉗ | Motor Supporter Upper |
| ㉘ | Crevice Nozzle |
| ㉙ | Round Brush |
| ㉚ | Park Position |
| ㉛ | Power Cord |
| ㉜ | Jacket |
| ㉝ | Cramp Hook |
| ㉞ | Screw SJ2823 |
| ㉟ | Mode Sticker |
| ㊱ | Extension Pipe(Plastic) |
| ㊲ | Long-square Nozzle |
| ㊳ | seal foil |

